



## *Transport Electronics*

2 Moonar Street, Carlton Beach, Tasmania, Australia 7173. A.B.N 86 538 707 991

Phone 03 62 658 585

Fax 03 62 657 585

Email [mike@transportelectronics.com](mailto:mike@transportelectronics.com)

---

### Remote Control Coding

Dismantle Agi controls to gain access to remote control receiver board, this needs to be done in the truck as controls need to be powered up for coding.

Switch on ignition, momentarily short the two **CC** pins on receiver board.

Connect the receiver to the transmitter with coding cable (transmitter coding socket is under battery cover).

The transmitter red led should now be on indicating coding mode is on.

Press transmitter **MIX** and **DISCHARGE** buttons simultaneously for 1 second, the transmitter led should blink twice to confirm successful coding and then switch off.

Disconnect coding cable.

Start truck check correct operation.

Reassemble Agi controls.